Step 1 Tacoma Hood Antenna Mount Install Instructions



Step by step on how to install the Hood Antenna Mount on the 3rd Gen Tacoma.

Installation Video: https://www.youtube.com/watch?v=V-4PdrMDJRc

Questions or Support:
Phone: 269-353-1184
Email: info@victory4x4.com

Step 2 Included Parts & Hardware



Check that you have all of the parts and hardware shown before starting.

Step 3 Mark Bracket Location



Remove the hood bolts on the passenger side. Hold the corner of the hood so it cannot fall into the windshield, and mark where the bracket goes with a sharpie.

Step 4 Remove Hood Bolts



Use a 12mm socket to remove the two hood bolts so the bracket can be installed.

Step 5 Line Up Bracket



Line the bracket up with the hinge. Make sure the hinge lines up with the marks you made with the sharpie.

Step 6 Reinstall Hood Bolts



Using a 12mm socket, reinstall the two factory bolts to secure the bracket to the hood.

Step 7 Install Antenna Base



Push up on the bottom of the bracket to push the threads through the hole. Install the small rubber washer with the brass nut on top.

Step 8 Tighten Brass Nut



Tighten the brass nut with channel locks, but do not overtighten. You are now finished with the install!

Step 9 Installation Complete



Congratulations, you have completed the install of your new Tacoma Hood Antenna Mount! Enjoy your new product.

Questions or Support:
Phone: 269-353-1184
Email: info@victory4x4.com