



Included Hardware:



Included Part(s):



3



Start by removing the plastic cover, below the rear window, with a pry tool or a flat head screw driver. Once removed, use a 10mm socket to remove the hex bolt. Be sure to hold onto this for later use.

4



Next, you need to remove the grab handles from each side of the vehicle. Pop off the plastic covers and remove the (2) factory hex bolts using a 10mm socket. Repeat this on each side of the vehicle.



5



Take the provided lower bracket and bolt it into place in the orientation shown above, using the provided long m6 bolt and spacer behind the bracket. Leave this loose for now so you can have adjustment if needed.

6



Now take the (2) provided upper brackets and bolt them into the factory holes that held the handle into place, using the provided longer hex heads with a washer. The handles can be installed over the brackets or left off. If leaving the handles off, the factory hardware can be reused. Install as shown in the orientation above. Leave this loose for now for adjustment.



## GX 550 & LC 250 Rear MOLLE System Install

Feedback?



7 With your brackets loosely bolted into place, bolt your molle panel to the lower bracket using the provided 1/4" button heads and a flange nuts.



8 Next, take the provided 1/4" hex heads with a washer and flange nut and bolt them to the top back bracket as shown above using a 7/16" wrench.



9



Once you have your panel attached to the brackets, repeat the same process for the opposite side. Once both panels are in the vehicle, take the upper shelf and place it on top of the brackets and align it so it is centered. Once positioned how you'd like it, tighten down all of the hardware for the panel brackets to secure everything into place.

10



With the upper shelf in place, drop bolts through the top into the brackets and use nuts to secure it into place. Once in place, take the provided back piece and the (2) upper brackets and bolt them all together and into the panel using 1/4" buttons heads and flange nuts.



11



Take the provided double sided 3M tape and cut to size of the last remaining brackets. Once cut to size peel one side of the tape off and place on the bottom side of the bracket, as shown above. Peel the other side of the tape, and feed the bracket through the logo hole and shimmy down to the mounting hole on the bracket and stick to the plastic and bolt into place.

12



To complete the install, take the provided stainless steel logo plate and bolt it into the cut out in the molle panel with the provided smaller button heads. Shown in the orientation above.



## GX 550 & LC 250 Rear MOLLE System Install

Feedback?



**13** Thank you for supporting American-made. We hope you enjoy your new product!

If you have any questions or concerns please reach out to us.

info@jcroffroad.com  
info@victory4x4.com  
info@squatch-proof.com  
info@fatamericanmfg.com

269-353-1184



**SQUATCH  
PROOF**

