



1



Included hardware: (3) 1/4"-20 button head screws, (3) 1/4" flat washers

2



Included items: Accessory mounting plate, Mounting bracket, Dual USB cable



3



First lift and remove the rubber compartment liner.

4



Next remove the two screws shown here using a 7mm socket.



2022+ Silverado 1500 DAM Install

Feedback?



5



Insert the mounting bracket in the orientation shown and secure it reusing factory hardware.

6

If you plan to install the provided USB cable you can now determine the best routing path to your intended power source. This can be a factory usb power port in the dash or an aftermarket 12v-5v usb adapter and this step will vary for each installation based on your preference and accessory power needs.



7



Route the cable ends through the top of the accessory mounting panel.

8



Pull all slack through and press the USB adapter tight into the rectangle cutout.



9



You can now route the USB cable ends to the desired power source location.

10



Line up the panel and install the 1/4" hardware. Start all 3 fasteners then tighten with a 5/32" hex.



11



Completed installation shown

12

**Thank you for supporting
American-made. We hope you
enjoy your new product!**

If you have any questions or concerns
please reach out to us.

info@jcroffroad.com
info@victory4x4.com
info@squatch-proof.com
info@fatamericanmfg.com

269-353-1184



**SQUATCH
PROOF**

