

How to use a Hand Liester




Ensure Liester is plugged in. Hold bottom button pressed until you hear it turn on.



Turn dial to desired temperature.



Follow video to show how to get nozzle into position and how to use roller while welding.



Check weld. To turn off Liester press and hold bottom dial until a snowflake appears on the display. Wait for cooldown.



Place Liester away from everything it will turn off after the cooldown ends.