

# How to use a Hand Liester




1 Ensure Liester is plugged in. Hold bottom button pressed in till you hear it turn on.



2 Turn dial to desired temperature.



3 Follow video to show how to get nozzle into position and how to use roller while welding.



4 Check weld. To turn off Liester press and hold bottom dial until a snowflake appears on the display. Wait for cooldown.



5 Place Liester away from everything it will turn off after the cooldown ends.