INST: VLC250-PET

Scan To Edit

1



Included Parts: Pet divider side sections | center section | upper and lower mounts.

2 Included Hardware: 28x 1/4"-20 x 1/2" black button heads | 2x 1/4"-20 x 3/4" Button Head Bolt | 30x 1/4"-20 serr. Flange nuts | 30x 1/4" washer

INST: VLC250-PET

3



Begin by bolting the panels together through the vertical face using the provided 1/4" hardware. It is best for the nuts to be on the face that will point towards the rear of the vehicle.

4



Install the same hardware through the top flange of each panel with the nuts on the bottom side.

5



Repeat the previous step on the bottom flange. The nuts should go on the top of the flange. Once all bolts are installed, they can be tightened.

6



Inside the vehicle, start from this point with both molle panels mostly installed aside from the top, front bracket. If installing with an upper shelf, make sure the front panel is not installed on it.

7



Loosely install the lower mounting brackets on each side. It should be mounted in the slots above the front mounting hole of the lower molle panel mount. This bracket can be flipped upside down depending on how far forward or backward you want the panel to sit.

8



Loosely install the pet divider onto the mounting brackets using two 1/4" bolts on each side. The bracket pictured has 4 bolt holes, but the production bracket will not.

9



Loosely install the upper mounting bracket. If installing with an upper shelf, the lower bolt will go through that as well in the location circled in red. This will require the longer 1/4"-20 x 3/4" long bolts provided with the upper shelf. Doing this may require moving the panel or basket forward or backward.

10



If installing with an upper shelf, secure the center of the panel to the shelf with 1/4" hardware.

11 Finally, adjust the position of everything to get it in the desired position and then tighten up all hardware and the install is complete.