

Included Hardware (Molle Panels + Upper Shelf): 6x M6 x 40mm Hex Head Bolt | 10x 1/4" Washer | 12x 1/4"-20 x 1/2" Button Head Bolt | 18x 1/4"-20 Serr. Flange Nuts | 2x 1/4"-20 x 3/4" Button Head Bolt | 4x 1/4"-20 x 1" Hex Head Bolt | 2x 1/2" OD Spacer | 4x VHB Adhesive



Included Part(s) (Molle Panels + Upper Shelf): 1x Upper Shelf | 1x Shelf Front Panel | 2x Upper Shelf Bracket | 2x Molle Panel | 2x Molle Panel Upper Rear Bracket | 2x Molle Panel Upper Front Bracket | 2x Molle Panel Lower Rear Bracket | 2x Molle Panel Lower Front Bracket | 2x Stainless Logo Plate



3



Start by removing the plastic cover, below the rear window, with a pry tool or a flat head screw driver. Once removed, use a 10mm socket to remove the hex bolt. Be sure to hold onto this for later use.

4



Next, you need to remove the grab handles from each side of the vehicle. Pop off the plastic covers and remove the (2) factory hex bolts using a 10mm socket. Repeat this on each side of the vehicle.



5



Take the provided lower bracket and bolt it into place in the orientation shown above, using the provided long m6 bolt and spacer behind the bracket. Leave this loose for now so you can have adjustment if needed.

6



Now take the (2) provided upper brackets and bolt them into the factory holes that held the handle into place, using the provided longer hex heads with a washer. The handles can be installed over the brackets or left off. If leaving the handles off, the factory hardware can be reused. Install as shown in the orientation above. Leave this loose for now for adjustment.



7 With your brackets loosely bolted into place, bolt your molle panel to the lower bracket using the provided 1/4" button heads and a flange nuts.



8 Next, take the provided 1/4" hex heads with a washer and flange nut and bolt them to the top back bracket as shown above using a 7/16" wrench.



9



Once you have your panel attached to the brackets, repeat the same process for the opposite side. Once both panels are in the vehicle, take the upper shelf and place it on top of the brackets and align it so it is centered. Once positioned how you'd like it, tighten down all of the hardware for the panel brackets to secure everything into place.

10



With the upper shelf in place, drop bolts through the top into the brackets and use nuts to secure it into place. Once in place, take the provided back piece and the (2) upper brackets and bolt them all together and into the panel using 1/4" buttons heads and flange nuts.



11



Take the provided double sided 3M tape and cut to size of the last remaining brackets. Once cut to size peel one side of the tape off and place on the bottom side of the bracket, as shown above. Peel the other side of the tape, and feed the bracket through the logo hole and shimmy down to the mounting hole on the bracket and stick to the plastic and bolt into place.


12



To complete the install, take the provided stainless steel logo plate and bolt it into the cut out in the molle panel with the provided smaller button heads. Shown in the orientation above.



13



Included Hardware (Pet Divider): 27x 1/4"-20 x 1/2" black button heads | 27x 1/4"-20 serr. flange nuts | 27x 1/4" black washer

14



Included Parts (Pet Divider): Pet divider side sections | center section | upper and lower mounts.




15



Begin by bolting the panels together through the vertical face using the provided 1/4" hardware. It is best for the nuts to be on the face that will point towards the rear of the vehicle.

16



Install the same hardware through the top flange of each panel with the nuts on the bottom side.



17



Repeat the previous step on the bottom flange. The nuts should go on the top of the flange. Once all bolts are installed, they can be tightened.

18



Inside the vehicle, start from this point with both molle panels mostly installed aside from the top, front bracket. If installing with an upper shelf, make sure the front panel is not installed on it.



19



Loosely install the lower mounting brackets on each side. It should be mounted in the slots above the front mounting hole of the lower molle panel mount. This bracket can be flipped upside down depending on how far forward or backward you want the panel to sit.

20



Loosely install the pet divider onto the mounting brackets using two 1/4" bolts on each side. The bracket pictured has 4 bolt holes, but the production bracket will not.



21



Loosely install the upper mounting bracket. the bottom bolt into the pet divider will need to be the longer 1/4" bolt provided in the molle panel bolt pack. If installing with an upper shelf, the lower bolt will go through that as well. doing this may require moving the panel or basket forward or backward.

22



If installing with an upper shelf, secure the center of the panel to the shelf with 1/4" hardware.



GX 550 & LC 250 Rear MOLLE System Install

Feedback?



23 Finally, adjust the position of everything to get it in the desired position and then tighten up all hardware and the install is complete.

24 **Thank you for supporting American-made. We hope you enjoy your new product!**

If you have any questions or concerns please reach out to us.

info@jcroffroad.com
info@victory4x4.com
info@squatch-proof.com
info@fatamericanmfg.com

269-353-1184



**SQUATCH
PROOF**

